

TACOMA

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
1995-04	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS, INTEGRIT BLACK	9.5XP, HS9500, XD9000, M8000	3423040 ¹⁰
1995-04	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS, SATIN BLACK	9.5XP, HS9500, XD9000, M8000	3423020 ¹¹
2005-11	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS ² , URETHANE BUFFERS, SATIN BLACK	9.5XP, HS9500, XD9000, M8000	3423030 ²
2005-11	WINCH BAR	AIRBAG APPROVED, OPTIONAL ARB FOG LIGHTS ¹ , RECESSED INDICATORS ² , URETHANE BUFFERS, SATIN BLACK	9.5XP, HS9500, XD9000, M8000	3423130 ²
2012-15	WINCH BAR	AIRBAG APPROVED, OPTIONAL ARB FOG LIGHTS ¹ , RECESSED INDICATORS ² , URETHANE BUFFERS, SATIN BLACK	9.5XP, HS9500, XD9000, M8000	3423140 ²
2016 ON	SUMMIT BAR	AIRBAG APPROVED, ARB FOG LIGHTS ^{3,4} , RECESSED LED INDICATORS, URETHANE BUFFERS, HILIFT JACK POINTS, SATIN BLACK	M8000, XD9000, XP9.5, XDC9.5, ZEON 8, 10, ZEON PLAT 10,	3423150K ^{5,6,7,8,9}

¹ ARB FOG LAMP KIT PART NO. 6821201. 3500440 LOOM REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS. ARB BUMPER WILL NOT ACCEPT FACTORY FOG LIGHTS.

² SOME VEHICLES MAY NEED 1156 LED BULBS INSTALLED IN ARB BUMPER IN ORDER FOR TURN SIGNALS TO WORK PROPERLY

³ OPTIONAL FOG LIGHT COVER KIT 3500680 AVAILABLE

⁴ ARB FOG LIGHTS AND LOOM ARE INCLUDED WITH BUMPER PART NUMBER 3423150K

⁵ 3423150K INCLUDES, TACOMA SUMMIT WINCH BUMPER, BUMPER FITTING KIT, WINCH INSTALL KIT, ARB FOG LIGHT KIT AND ARB FOG LIGHT LOOM

⁶ OPTIONAL HAWSE FAIRLEAD SPACER KIT PART NUMBER 3500600 REQUIRED WHEN FITTING A HAWSE FAIRLEAD.

⁷ OPTIONAL FLIP-UP LICENSE PLATE BRACKET PART NUMBER 3500630 REQUIRED WHEN FITTING FROM LICENSE PLACE

⁸ WARN PART NO W89965 REQUIRED WHEN FITTING WARN ZEON AND ZEON PLATINUM WINCH

⁹ WARN PART NO W94288 ENHANCED SIGNAL KIT MAY BE NEEDED WHEN FITTING WARN ZEON PLATINUM WINCH

¹⁰ FINISHED IN INTEGRIT BLACK TEXTURED POWDER COAT

¹¹ FINISHED IN SATIN BLACK POWDER COAT

ARB RECOVERY POINT		
YEAR	DESCRIPTION	PART NO.
2016 ON	ARB RECOVERY POINT - RHS - 17,5000 LB RATING	2823010

UNDER VEHICLE PROTECTION KIT		
YEAR	DESCRIPTION	PART NO.
2005 ON	UNDER VEHICLE PROTECTION KIT	5423010

ARB SUMMIT SIDE RAILS AND STEPS		
YEAR	DESCRIPTION	PART NO.
2016 ON	SUMMIT PROTECTION STEPS - DOUBLE CAB AND ACCESS CAB - BLACK INTEGRIT FINISH	4423010 ¹
	SUMMIT FRONT PROTECTION RAILS - PROTECTS FENDERS, ATTACHES TO ARB FRONT SUMMIT BAR	4423020 ¹
	SUMMIT PROTECTION STEPS RETURN	4423030 ¹

¹ ORDER PART No 4423010 AND 4423020 FOR STEPS AND SIDE RAILS. ORDER PART No 4423010 AND 4423030 FOR JUST THE STEPS

ARB REAR SUMMIT BAR			
YEAR	DESCRIPTION	FEATURES	PART NO.
2016 ON	REAR SUMMIT BAR	WORKS WITH FACTORY HITCH, WORKS WITH REAR PARK SENSORS, HI-LIFT JACK POINTS, PRESS FORMED WINGS, ANODIZED EXTRUSION STEP, BLACK INTEGRIT FINISH	3623040

ARB ROOF RACK		
YEAR	DESCRIPTION	PART NO.
2005 ON	ARB STEEL NON MESH ROOF RACK - 52"X44"	3800250
	ARB STEEL TRADE ROOF RACK - 52"X44"	3800253
REQ.	ARB ROOF RACK FITTING KIT - REQUIRED WHEN FITTING PART NO 3800250 OR 3800253 RACKS	3723010



OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1998-04	COMPLETE KITS	STOCK/LIGHT LOAD (0-110LBS)	KIT	2"	1	OMETAC04LKS ⁶
		HEAVY LOAD (110-220LBS)	KIT	2"	1	OMETAC04HKS ⁶
	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.75"	1	2880 ¹
		NITROCHARGER SPORT	STRUT		2	90004
		HEAVY LOAD (110-220LBS)	SPRING	1.75"	1	2881 ¹
		NITROCHARGER SPORT	STRUT		2	90004
	REAR	MEDIUM LOAD	SPRING	2.25"	1+1	CS046RA/B ²
		NITROCHARGER SPORT	SHOCK			*60065/60062
	REQ'D FOR INSTALLATION	REAR LEAF SPRING BUSHING KIT			2	OMESB89 ³
		EXHAUST BRACKET			1	FK21 ⁴
	OPTIONAL	FRONT TRIM SPACER 5MM			1	OME95PF5
		REAR GREASABLE SHACKLE KIT			1	OMEGB12 ³
		REAR GREASABLE BUSHING KIT			2	OMESB88 ³
		EXTRA LEAF			2	D43XL ⁷

¹ OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

² FOR LIGHT LOAD APPLICATIONS, THE 2ND LEAF FROM THE BOTTOM OF THE SPRING PACK CAN BE REMOVED FOR IMPROVED RIDE COMFORT. CS046RA/B REAR LEAF SPRINGS ONLY FIT POST 1998 XTRA CAB AND DOUBLE CAB MODELS.

³ OMESB89 MUST BE USED WITH ORIGINAL SHACKLES. OMESB88 MUST BE USED WITH OMEGB12 GREASABLE SHACKLES. OE RUBBER BUSHINGS ARE USED AT FIXED END OF SPRING. INSTALL ORIGINAL OE BUSHINGS FROM OE SPRINGS IF THEY ARE IN GOOD CONDITION, OR SOURCE NEW OE BUSHINGS FROM DEALERSHIP.

⁴ FK21 EXHAUST BRACKET IS A MANDATORY FITMENT TO ENSURE EXHAUST SYSTEM CLEARS SPRINGS.

⁵ KIT CONTAINS STANDARD OLD MAN EMU NITROCHARGER SHOCKS

⁶ KIT CONTAINS OLD MAN EMU NITROCHARGER SPORT SHOCKS

⁷ ADD EXTRA LEAF TO REAR SPRING PACK WHEN CARRYING 220LBS AS A HEAVY CONSTANT LOAD.

* FIRMER SHOCK

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
2005-15	COMPLETE KITS	STOCK/LIGHT LOAD (0-110LBS)	KIT	2"	1	OMETAC05LKS ^{1,5}
		HEAVY LOAD (110-220LBS)	KIT	2"	1	OMETAC05HKS ^{1,5}
		LIGHT LOAD/HEAVY LOAD BP-51 KIT	KIT	2"	1	OMETAC16BP51B ^{1,7}
	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.75"	1	2885 ⁴
		NITROCHARGER SPORT	STRUT		2	90021
		HEAVY LOAD (110-220LBS)	SPRING	1.75"	1	2886 ⁴
		NITROCHARGER SPORT	STRUT		2	90000
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.75"	2	EL095R
		NITROCHARGER SPORT	SHOCK		2	60091
	REAR	HEAVY CONSTANT 660LB LOAD	SPRING	2.75"	2	EL096R
		NITROCHARGER SPORT	SHOCK		2	60091
	REQUIRED	FITTING KIT			1	FK29 ³
		U BOLTS			4	OMEU53B
		REAR SPRING BUSHING KIT			2	OMESB108
OPTIONAL	EXTRA LEAF			2	SEE NOTE ²	
	TRIM PACKER ⁶				OME95PF5 ⁶	

¹ KIT NOW INCLUDES LEAF SPRING LEAF SPRING BUSHING KIT.

² TO INCREASE LOAD, USE PART NUMBER D29XL FOR "CS" SPRINGS AND EL46XL FOR "EL" SPRINGS.

³ DRIVESHAFT PACKER KIT IS DESIGNED TO SPACE DOWN CARRIER BEARING TO REDUCE TAIL SHAFT FLANGE ANGLE, THEREBY REDUCING DRIVELINE VIBRATION.

⁴ OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

⁵ KIT CONTAINS STANDARD OLD MAN EMU NITROCHARGER SPORT SHOCKS AND STRUTS

⁶ TRIM PACKER PART No. OME95PF5 IS DESIGNED TO TRIM VEHICLE FROM DRIVER TO PASSENGER SIDE. NOT TO BE USED FOR ADDITIONAL LIFT.

⁷ KIT CONTAINS OME ADJUSTABLE INTERNAL BYPASS BP-51 COILOVERS AND SHOCKS

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
2016-ON	COMPLETE KITS	STOCK/LIGHT (NO ARB BUMPER)	KIT	2"	1	OMETAC16LKSB ^{3,7}
		MEDIUM LOAD (FT ARB BUMPER, NO WINCH)	KIT	2"	1	OMETAC16MKSB ^{3,7}
		HEAVY LOAD (FRT ARB BUMPER & WINCH)	KIT	2"	1	OMETAC16HKSB ^{3,7}
		LIGHT LOAD/HEAVY LOAD BP-51 KIT	KIT	2"	1	OMETAC16BP51B ^{3,8}
	FRONT	STOCK/LIGHT LOAD (NO ARB BUMPER)	SPRING	2"	1	2887 ¹
		NITROCHARGER SPORT	STRUT		2	90021 ^{5,6}
		MEDIUM LOAD (WITH ARB BUMPER)	SPRING	2"	1	2888 ¹
		NITROCHARGER SPORT	STRUT		2	*90000 / 90021 ^{5,6}
		HEAVY LOAD (WITH ARB BUMPER & WINCH)	SPRING	2"	1	2886 ¹
		NITROCHARGER SPORT	STRUT		2	90000 ^{5,6}
	REAR	MEDIUM LOAD	SPRING	2"	2	EL095R
		NITROCHARGER SPORT	SHOCK		2	60091
		HEAVY CONSTANT 660LB LOAD	SPRING	2"	2	EL096R
		NITROCHARGER SPORT	SHOCK		2	60091
	REQ'D FOR INSTALLATION	FITTING KIT			1	FK29 ²
		U BOLTS			4	OMEU53B
		REAR SPRING BUSH KIT			2	OMESB108
	OPTIONAL	EXTRA LEAF			2	SEE NOTE ^{4,10}
		LEAF SPRING CENTER BOLT			2	UCB17 ⁴
		TRIM PACKER 5MM				OME95PF5 ⁹
		UPPER STRUT BUSHINGS			1	OME3133 ⁵
STRUT TOP HAT KIT				1	OMETH002 ⁶	

¹ OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

² DRIVESHAFT PACKER KIT IS DESIGNED TO SPACE DOWN CARRIER BEARING TO REDUCE TAIL SHAFT FLANGE ANGLE, THEREBY REDUCING DRIVELINE VIBRATION.

³ FOR REAR MEDIUM LOAD SPRING REMOVAL OF 3RD LEAF IS REQUIRED

⁴ UCB17 x2 REQUIRED WHEN FITTING EL46XL OR D29XL EXTRA LEAF

⁵ NO TOP MOUNTING BUSHINGS ARE SUPPLIED, USE OME3133. OE BUSHINGS MAY BE RE-USED IF IN GOOD CONDITION.

⁶ STRUT TOP HAT KIT MAY BE REQUIRED IF ORIGINAL EQUIPMENT IS WORN.

⁷ KIT IS SUPPLIED WITH OME NITROCHARGER SPORT STRUTS AND SHOCKS

⁸ KIT IS SUPPLIED WITH OME BP-51 ADJUSTABLE INTERNAL BYPASS SHOCKS AND COILOVERS

⁹ TRIM PACKER PART No. OME95PF5 IS DESIGNED TO TRIM VEHICLE FROM DRIVER TO PASSENGER SIDE. NOT TO BE USED FOR ADDITIONAL LIFT.

¹⁰ TO INCREASE LOAD, USE PART NUMBER D29XL FOR "CS" SPRINGS AND EL46XL FOR "EL" SPRINGS.

* FIRMER VALVING

OPTIONAL OME BP-51 COILOVER & SHOCK ABSORBERS

MODEL	LOCATION	DESCRIPTION	LIFT	QUANTITY	PART NO.
2005-16	FRONT	OME BP-51 INTERNAL BYPASS COILOVER - FRONT RIGHT	2"	1	BP5190006R ^{1,2}
		OME BP-51 INTERNAL BYPASS COILOVER - FRONT LEFT	2"	1	BP5190006L ^{1,2}
	REAR	OME BP-51 INTERNAL BYPASS SHOCK - REAR RIGHT		1	BP5160011R ³
		OME BP-51 INTERNAL BYPASS SHOCK - REAR LEFT		1	BP5160011L ³
VEHICLE MOUNT KITS	VEHICLE MOUNT KIT - FRONT - REQUIRED FOR BP-51 FITMENT			1	VM80010016 ²
	VEHICLE MOUNT KIT - REAR - REQUIRED FOR BP-51 FITMENT			1	VM80010017 ³

¹ OME BP-51 COILOVERS COME PRE LOADED WITH OME COIL SPRINGS.

² VEHICLE MOUNT KIT REQUIRED WHEN FITTING OME BP-51 COILOVER PART NO BP5190006R & BP5190006L

³ VEHICLE MOUNT KIT REQUIRED WHEN FITTING OME BP-51 SHOCK PART NO BP5160011R & BP5160011L

IPF LIGHTING & ACCESSORIES

YEAR	MODEL	RECOMMENDED LIGHTING
ALL	3423020	ARB INTENSITY LED, 900DB, 800SXD, 901XSD, 901XSS, 901HIDD, 901HIDS, 868CS, 968CSG

SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
1995-04	TOYOTA TACOMA V6 SNORKEL	SS170HF
2005-15	TOYOTA TACOMA V6 SNORKEL	SS171HP
2016 ON	TOYOTA TACOMA V6 SNORKEL	SS172HP

REFER TO WWW.SAFARI4X4.COM.AU FOR DETAILS.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1996-04	FRONT	7.5" DIA. RG, 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
2005-ON	FRONT	8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.91 & UP	RD111 ²
		8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.73 & DN	RD121 ²
1996-15	REAR	8.4" DIA. RG, 12 BOLT	33 (1.31")	30	ALL	RD129 ¹
2016-ON	REAR	8.0" DIA. RG, ALL AUTOS EXCLUDING OE LOCKER EQUIPPED	33 (1.31")	30	ALL	RD132
		8.9" DIA. RG, ALL MANUALS & ALL OE LOCKER EQUIPPED	34.8 (1.37")	32	ALL	RD232

¹ LOCKER SUITS OPEN DIFFERENTIALS ONLY, AND WILL NOT REPLACE THE FACTORY E-LOCKER UNLESS THE HOUSING AND 3RD MEMBER ARE REPLACED WITH OPEN END DIFFS.

² FACTORY R&P MAY USE EITHER RD111 OR RD121 DEPENDING ON THE RATIO. ALL KNOWN AFTERMARKET R&P SETS USE RD121