LAND ROVER

DEFENDER 90 & 110

ARB DELUXE BULL BARS & WINCH BARS						
YEAR	MODEL	FEATURES	WINCHES	PART NO.		
1985 ON	WINCH BAR D90	RECESSED INDICATORS, HI-LIFT JACK POINTS, FACTORY STYLE JACKING POINTS, INTEGRATED TOW POINTS, CB AERIAL MOUNTS	M12000, XP9500, XDC9500, XD9000	34323001,4		
1985-12/01	WINCH BAR D90	RECESSED INDICATORS, TOW POINTS, BLACK	M12000, XD9000 ²	3432090		
1985 ON	WINCH BAR D110	RECESSED INDICATORS, HI-LIFT JACK POINTS, FACTORY STYLE JACKING POINTS, INTEGRATED TOW POINTS, CB AERIAL MOUNTS,	M12000, XP9500, XDC9500, XD9000	3432300¹		
1985 ON	WINCH BUMPER D90 & D110	RECESSED INDICATORS, TOW POINTS, HI-LIFT JACK POINTS, CB MOUNTS,	M12000, XD9000 XP95000, XDC9500	3932400 ^{1,3}		

- Winch install kit part no. 3532070 required when fitting a winch.
- 2 $\,$ Requires spacer kit part no. 3532050 to mount 8/9000lb winches in this bar.
- 3 Bumper replacement. Does not have headlight grill protection bars like tradition ARB bullbars
- 4 1997 NORTH AMERICAN SPEC (NAS) DEFENDER 90 HEADLAMP SURROUND ASSEMBLIES DO NOT CLEAR BUMPER. SURROUNDS AND INDICATORS FROM 1993-96 MODEL YEAR VEHICLES WILL BE REQUIRED WHEN FITTING BUMPER.

IPF LIGHTING & ACCESSORIES				
YEAR	TYPE	RECOMMENDED LIGHTING		
1985 ON	ALL	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG		
		920HJKTJ - 7" ROUND H4 HEADLIGHT CONVERSION KIT WITHOUT BULBS		

SAFARI SNORKEL					
YEAR	RECOMMENDED SNORKEL PART NO.				
1990-94	D90 200 SERIES 2.5L TDI DIESEL LHS MOUNT	SS500HF			
	D90 200 SERIES 3.5L V8 PETROL RHS MOUNT	SS525HF			
3/1994-ON	D90 300 SERIES 2.5L TDI DIESEL RHS MOUNT	SS550HF			
1999-ON	D90 TD5 2.5 TDI DIESEL RIGHT HAND DRIVE ONLY	SS575HFABS			
1999-ON	D90 TD5 2.5 TDI DIESEL LEFT HAND DRIVE ONLY	SS575HFLHD			

REFER TO WWW.SAFARI4x4.COM.AU FOR DETAILS.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1983-93	FRONT	110 ROVER TYPE	28.2 (1.11")	10	3.54	RD1271
1993-2015	FRONT		31.5 (1.24)	24	3.54	RD128 ¹
1983 2/2002	REAR	110 SALISBURY TYPE	31.5 (1.24")	24	3.54	RD161
3/2002-2015	REAR	110 ROVER TYPE W/ TRACTION CONTROL	31.5 (1.24")	24	3.54	RD138
1984-93	FRONT	90 ROVER TYPE	28.2 (1.11")	10	3.54	RD1271
1993-2015	FRONT		31.5 (1.24")	24	3.54	RD128 ^{1,2}
1983-93	REAR	90 ROVER TYPE, 4 CYL, PETROL/DIESEL	28.2(1.11")	10	3.54	RD127 ¹
1984-1993	REAR	ROVER TYPE, V8 PETROL ENGINE	31.5 (1.24")	24	3.54	RD128 ¹
1993-2015	REAR	90 ROVER TYPE	31.5 (1.24")	24	3.54	RD128 ^{1, 2,}

¹ If vehicle was manufactured during 1993, check spline count.



 $^{^{2}\,\,}$ $\,$ Some vehicles may have crown wheel bolts which cannot be reused and must be replaced.

 $^{^3}$ Some vehicles without traction control also use RD138. Identify by 205mm (8.07") flange dia.

LAND ROVER

DEFENDER 90 & 110

OLD MAN EMU S	SUSPENSION SYS	TEMS				
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
DEFENDER 110	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.25"	1	2761
		NITROCHARGER SPORT	SHCOK		2	60037
		HEAVY LOAD (110-220LBS)	SPRING	1.50"	1	2767
		NITROCHARGER SPORT	SHOCK			60037
		HEAVY CONSTANT (220-350LBS)	SPRING	1.25"	1	2766
		NITROCHARGER SPORT	SHOCK		2	60037
	REAR	LIGHT LOAD (0LBS TO GVW)	SPRING	1.50"	1	2752¹
		NITROCHARGER SPORT	SHOCK		2	600387
		CONSTANT LOAD (660LBS TO GVW)	SPRING	2.0"	1	2755
		NITROCHARGER SPORT	SHOCK		2	60039 ⁷
		HEAVY CONSTANT (1,100LBS TO GVW)	SPRING	1.50"	1	2754²
		NITROCHARGER SPORT	SHOCK		2	60039
	REQUIRED	CASTER KIT			1	SEE BELOW ³
	FOR INSTALL	STEERING DAMPER			1	OMESD32
	OPTIONAL	NITROCHARGER SPORT EXTENDED LENGTH	TH FRONT SHOCKS	3	2	60037L
		NITROCHARGER SPORT EXTENDED LENGTH	TH REAR SHOCKS		2	60039L
		DEFENDER 110 BP-51 INTERNAL BYPASS S	HOCK - FRONT		2	BP5160035 ^{4,6}
		DEFENDER 110 BP-51 INTERNAL BYPASS S	HOCK - REAR		2	BP5160036 ^{5,6}
		DEFENDER 110 BP-51 VEHICLE MOUNT KIT	- FRONT		1	VM80010036 ⁴
		DEFENDER 110 BP-51 VEHICLE MOUNT KIT	- REAR		1	VM80010037 ⁵
		DEFENDER 110 FRONT LIGHT LOAD SPRIN	G (NO BUMPER) - 2	" LIFT	1	3062
		DEFENDER 110 FRONT HEAVY LOAD SPRIN	NG (BAR & WINCH) -	· 2" LIFT	1	3063
		DEFENDER 110 REAR MEDIUM LOAD SPRIN	NG - 2" LIFT		1	3064
		DEFENDER 110 REAR HEAVY LOAD 660LB (CONSTANT SPRING	i - 2" LIFT	1	3065
		DEFENDER 110 REAR HEAVY LOAD 1100LB	CONSTANT SPRING	G - 2" LIFT	1	3066
DEFENDER 90	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.25"	1	2761
		NITROCHARGER SPORT	SHOCK		2	60037
		HEAVY LOAD (110-220LBS)	SPRING	1.25"	1	2751
		NITROCHARGER SPORT	SHOCK		2	60037
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	1.50"	1	2764
		NITROCHARGER SPORT	SHOCK		2	60038
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	2.0"	1	2762
		NITROCHARGER SPORT	SHOCK		2	60039
	REQ'D FOR INSTALLATION	CASTER KIT			1	SEE BELOW ³
		STEERING DAMPER			1	OMESD32
	OPTIONAL	NITROCHARGER SPORT EXTENDED LENGT	TH FRONT SHOCKS	3	2	60037L
		NITROCHARGER SPORT EXTENDED LENGT	TH REAR SHOCKS		2	60039L

- 2752 COIL HAS A SOFTER SPRING RATE THAN OE COIL. THIS IS TO PROVIDE IMPROVED RIDE QUALITY WITH LIGHT LOADS ONLY.
- 2 $\;$ Where original springs have an inner helper coil, be sure to refit helper coil when installing OME coils.
- 3 CAUTION: DUE TO ALTERED GEARBOX MOUNTS ON MODELS AFTER 1998 ANY LIFT ABOVE OE RIDE HEIGHT MAY CAUSE FRONT DRIVELINE VIBRATION THAT CAN ONLY BE RECTIFIED BY FITMENT OF FRONT DOUBLE CARDAN JOINTS. CASTER KIT WILL INCREASE CASTER ANGLE BY 2 DEGREES. CHECK MANUFACTURER'S SPECIFICATIONS TO DETERMINE IF CASTER KIT IS REQUIRED. CALR1 SUITS 38MM WIDE "A" ARMS. CALR2 SUITS 44MM WIDE "A" ARMS.
- 4 Vehicle mount kit part number VM80010036 required when fitting BP5160035 BP-51 shock.
- 5 Vehicle mount kit part number VM80010037 required when fitting BP5160036 BP-51 shock.
- $^{\rm 6}$ $\,$ Shocks are developed to only work with OME 3062-3066 2" coil springs.
- FOR HIGH ARTICULATION VEHICLES IT IS RECOMMENDED TO REPLACE THE REAR UPPER SHOCK MOUNT WITH FK64 AND MATCHING SHOCKS 60146 (LIGHT LOAD) or 60147 (CONSTANT/HEAVY CONSTANT LOAD).

