

## 4RUNNER

### ARB DELUXE BULL BARS & WINCH BARS

YEAR	MODEL	FEATURES	WINCHES	PART NO.
2014-19	SUMMIT BAR INTEGRIT FINISH	SRS APPROVED, INDICATORS, RECESSED FOG LAMPS, LED INDICATORS, HI-LIFT JACK POINTS	M8000, XD9000, XP9.5, XDC9.5, ZEON 8 <sup>4,6</sup> , 10 <sup>4,6</sup> , ZEON PLATINUM	3421560K <sup>3,4,5,6,7,8</sup>
2010-13	WINCH BAR	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS <sup>2</sup> , SATIN BLACK FINISH	9.5XP, HS9500, XD9000	3421520
2006-09	WINCH BAR INTEGRIT FINISH	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS <sup>2</sup> , INTEGRIT BLACK FINISH	9.5XP, HS9500, XD9000,	3421540
2003-05	WINCH BAR	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS <sup>2</sup> , INTEGRIT BLACK FINISH	9.5XP, HS9500, XD9000,	3421530
1986-95	WINCH BAR	RECESSED INDICATORS, TOW POINTS, BLACK	XD9000, M8000	3414070 <sup>1</sup>

<sup>1</sup> FITMENT OF BAR TO 4RUNNER MODELS MAY REQUIRE MODIFICATIONS - CONTACT ARB FOR DETAILS.

<sup>2</sup> OPTIONAL ARB FOG LAMP KIT PART NO. 6821201 (HALOGEN) OR 3500890 (LED) AVAILABLE. 3500440 (SUITS HALOGEN) OR 3500520 (SUITS LED) LOOM REQUIRED WHEN FITTING OPTIONAL FOG LAMP KIT.

<sup>3</sup> 3421560K INCLUDES SUMMIT COMBO BAR, ARB RECESSED HALOGEN FOG LAMPS AND FOG LAMP HARNESS

<sup>4</sup> OPTIONAL HAWSE FAIRLEAD SPACER KIT PART NO 3500600 REQUIRED WHEN FITTING A HAWSE FAIRLEAD

<sup>5</sup> OPTIONAL ROLLER FAIRLEAD COVER 3500850 AVAILABLE

<sup>6</sup> WARN PART NO W89965 REQUIRED WHEN FITTING WARN ZEON AND ZEON PLATINUM WINCH

<sup>7</sup> DESIGNED FOR SR5, TRAIL AND TRD MODELS. **WILL NOT FIT LIMITED MODELS.**

<sup>8</sup> OPTIONAL ARB FOG LAMP KIT PART NO. 3500590 (HALOGEN) OR 3500890 (LED) AVAILABLE. 3500590 (SUITS HALOGEN) OR 3500520 (SUITS LED) LOOM REQUIRED WHEN FITTING OPTIONAL FOG LAMP KIT.

### SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
2010-19	SAFARI ARMAX SNORKEL - 4RUNNER 5TH GENERATION - ALL ENGINES	SS450HP
2003-09	SAFARI SNORKEL - 4RUNNER 4TH GENERATION - 4.7L V8	SS440HF
2003-09	SAFARI SNORKEL - 4RUNNER 4TH GENERATION - 4.0L V6	SS445HF
1989-94	3.0L, V6 SNORKEL - NEEDS MODIFICATIONS	SS130HF
1984-88	2.0L/2.2L SNORKEL - NEEDS MODIFICATIONS	SS65HF

### UNDER VEHICLE SKID PLATES

YEAR	DESCRIPTION	PART NO.
2010-19	2010-19 TOYOTA 4RUNNER WITH KINETIC (KDSS) SYSTEM	5421110
2010-19	2010-19 TOYOTA 4RUNNER WITHOUT KINETIC (KDSS) SYSTEM	5421100

### ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
2003-ON	FRONT	8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.91 & UP	RD111 <sup>3</sup>
		8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.73 & DN	RD121 <sup>3</sup>
TO 2002	FRONT	8" DIA. RG. 10 BOLT, LIVE AXLE	33 (1.31")	30	ALL	RD132
		7.5 DIA. RG 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
1984-88	REAR	4 CYLINDER, 45MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 <sup>1</sup>
1988-09	REAR	V6, 4WD, 50MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 <sup>2</sup>
		V6,2WD, 45MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 <sup>1,2</sup>
2010-ON	REAR	8.25" DIA RG, 12-BOLT (SHIMMED)	33 (1.31")	30	ALL	RD193 <sup>2</sup>

<sup>1</sup> LATE MODEL 50.00MM (1.969") ID BEARINGS MUST BE USED WITH THIS SPECIFIC APPLICATION. (ARB PART No. 160116)

<sup>2</sup> SUITS OPEN DIFFERENTIAL CARRIERS ONLY. WILL NOT WORK WITH FACTORY LOCKER OPTIONED 3RD MEMBERS

<sup>3</sup> ON LOWER GEAR RATIOS (4.56, 4.88 ETC), GEARS MAY BE AVAILABLE TO FIT THE RD111 OR THE RD121. CHECK WITH YOUR GEAR SUPPLIER TO DETERMINE WHICH AIR LOCKER IS CORRECT FOR YOU.

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
2010 CURRENT	COMPLETE KITS	MEDIUM LOAD BP-51 KIT - NON KDSS	KIT	3"	1	OME4RNR10MKBP51
		HEAVY LOAD BP-51 KIT - NON KDSS	KIT	3"	1	OME4RNR10HKBP51
		MEDIUM LOAD BP-51 KIT - WITH KDSS	KIT	3"	1	OME4RNR10MKBP51KD
		HEAVY LOAD BP-51 KIT - WITH KDSS	KIT	3"	1	OME4RNR10HKBP51KD
		MEDIUM LOAD BP-51 KIT - NON KDSS - WITH UPPER CONTROL ARMS	KIT	3"	1	4RBP51MP
		HEAVY LOAD BP-51 KIT - NON KDSS - WITH UPPER CONTROL ARMS	KIT	3"	1	4RBP51HP
		MEDIUM LOAD BP-51 KIT - WITH KDSS - WITH UPPER CONTROL ARMS	KIT	3"	1	4RBP51MKP
		HEAVY LOAD BP-51 KIT - WITH KDSS - WITH UPPER CONTROL ARMS	KIT	3"	1	4RBP51HKP

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2010-CURRENT	FRONT	LIGHT LOAD - STOCK WEIGHT - NO BAR OR WINCH	SPRING	3"	1	2884 <sup>4</sup>	
		NITROCHARGER SPORT	STRUT		2	90010 <sup>5</sup>	
		MEDIUM LOAD - WITH BAR OR WINCH ONLY (70-180LBS)	SPRING	3"	1	2885 <sup>4</sup>	
		NITROCHARGER SPORT	STRUT		2	90010 <sup>5</sup>	
		HEAVY LOAD - WITH BAR AND WINCH (230LBS+)	SPRING	3"	1	2887 <sup>4</sup>	
		NITROCHARGER SPORT	STRUT		2	90010 <sup>5</sup>	
		OPTIONAL	FRONT TRIM SPACER 5MM				OME95PF5 <sup>1</sup>
			FRONT UPPER CONTROL ARMS	UCA		1	UCA0004
		REAR	MEDIUM LOAD	SPRING	3"	1	2889
			NITROCHARGER SPORT	SHOCK		2	60080 <sup>6</sup>
	HEAVY LOAD (440LBS CONSTANT LOAD)		SPRING	3"	1	2898	
	NITROCHARGER SPORT		SHOCK		2	*60081/60080 <sup>6</sup>	
	HEAVY LOAD (880LBS CONSTANT LOAD)		SPRING	3"	1	2899	
	NITROCHARGER SPORT		SHOCK		2	60081 <sup>3</sup>	
OPTIONAL	OPTIONAL REAR SPORT SHOCK GUARD				OME661		
OPTIONAL BP-51 INTERNAL BYPASS	VEHICLES WITHOUT KDSS SYSTEM	BP-51 COIL OVER - FRONT RHS	COIL OVER	3"	1	BP5190002R <sup>1</sup>	
		BP-51 COIL OVER - FRONT - LHS	COIL OVER	3"	1	BP5190002L <sup>1</sup>	
		BP-51 SHOCK - REAR	SHOCK		2	BP5160025 <sup>2</sup>	
		VEHICLE MOUNT KIT FRONT	MOUNT KIT		1	VM80010028 <sup>1</sup>	
		VEHICLE MOUNT KIT REAR	MOUNT KIT		1	VM80010010 <sup>2</sup>	
	VEHICLES WITH KDSS SYSTEM	BP-51 COIL OVER - FRONT - RHS	COIL OVER	3"	1	BP5190002R <sup>3</sup>	
		BP-51 COIL OVER - FRONT - LHS	COIL OVER	3"	1	BP5190004L <sup>3</sup>	
		BP-51 SHOCK - REAR	SHOCK		2	BP5160025 <sup>2</sup>	
		VEHICLE MOUNT KIT FRONT	MOUNT KIT		1	VM80010009 <sup>3</sup>	
		VEHICLE MOUNT KIT REAR	MOUNT KIT		1	VM80010010 <sup>2</sup>	

<sup>1</sup> VEHICLE MOUNT KIT PART NUMBER **VM80010028** REQUIRED WHEN FITTING BP-51 PART NUMBER **BP5190002R** AND **BP5190002L**

<sup>2</sup> VEHICLE MOUNT KIT PART NUMBER **VM80010010** REQUIRED WHEN FITTING BP-51 PART NUMBER **BP5160025**

<sup>3</sup> VEHICLE MOUNT KIT PART NUMBER **VM80010009** REQUIRED WHEN FITTING BP-51 PART NUMBER **BP519002R** AND **BP5190004L**

<sup>4</sup> VEHICLES WITH KDSS MUST HAVE 1 x OME95PF5 SPACER INSTALLED ON THE DRIVER'S SIDE TO MAINTAIN CORRECT TRIM.

<sup>5</sup> NO TOP MOUNT BUSHING SUPPLIED, USE OME3133. OE BUSHINGS MAY BE REUSED IF IN GOOD CONDITION.

<sup>6</sup> OME661 LOWER SHOCK MOUNT STONE GUARD IS RECOMMENDED FOR REAR SHOCKS TO PROTECT AGAINST STONE CHIP DAMAGE.

\* FIRMER VALVED SHOCK

## 4RUNNER

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2003-09 MODELS	FRONT	LIGHT LOAD - STOCK WEIGHT - NO BAR OR WINCH	SPRING	1.0"	1	2884 <sup>1</sup>	
		NITROCHARGER SPORT	STRUT		2	*90000 / 90021	
		MEDIUM LOAD - WITH BAR OR WINCH ONLY (70-180LBS)	SPRING	2.0"	1	2885 <sup>1</sup>	
		NITROCHARGER SPORT	STRUT		2	90000	
		HEAVY LOAD - WITH BAR AND WINCH (230LBS+)	SPRING	2.5"	1	2886 <sup>1</sup>	
		NITROCHARGER SPORT	STRUT		2	90000	
	REAR	MEDIUM LOAD	SPRING	2.0"	1	2895	
		NITROCHARGER SPORT	SHOCK		2	60004	
		HEAVY LOAD (330LBS TO GVW)	SPRING	2.0"	1	2896	
		NITROCHARGER SPORT	SHOCK		2	*60005/60004	
		HEAVY CONSTANT LOAD (660LBS TO GVW)	SPRING	2.0"	1	2897	
		NITROCHARGER SPORT	SHOCK		2	60005	
	OPTIONAL	FRONT UPPER CONTROL ARMS				1	UCA0004
		FRONT TRIM SPACER 5MM					OME95PF5

<sup>1</sup> IMPORTANT: OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUT AND COIL SEATS.

\* FIRMER VALVE SHOCK

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
1996-02 MODELS	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.25"	1	2880	
		NITROCHARGER SPORT	SHOCK		2	90004	
		HEAVY LOAD (110-240LBS)	SPRING	1.25"	1	2881	
		NITROCHARGER SPORT	SHOCK		2	90004	
	REAR	MEDIUM LOAD	SPRING	2.0"	1	2906	
		NITROCHARGER SPORT - SOFT VALVING	SHOCK		2	60073	
		NITROCHARGER SPORT - FIRM VALVING	SHOCK		2	60028	
		HEAVY LOAD (330LBS TO GVW)	SPRING	2.0"	1	2890	
		NITROCHARGER SPORT	SHOCK		2	60027	
		HEAVY CONSTANT LOAD (660LBS TO GVW)	SPRING	2.0"	1	2891	
		NITROCHARGER SPORT	SHOCK		2	60027	
		OPTIONAL	FRONT TRIM PACKER 5MM				
	REAR TRIM PACKER 5MM						OME80PF05
	REAR TRIM PACKER 10MM						OME80PF10

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
IFS REAR LEAF SPRING PRE 1990 & IFS REAR COILS SPRING 1990-95	FRONT	STOCK/LIGHT LOAD	TORSION	N/A	1	303003 <sup>1</sup>
		NITROCHARGER SPORT	SHOCK		2	60072
IFS REAR COIL SPRING MODELS 1990-95	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	1.5"	1	2900
		NITROCHARGER SPORT	SHOCK		2	60073
		HEAVY LOAD (330LBS CONSTANT LOAD)	SPRING	1.5"	1	2901
		NITROCHARGER SPORT	SHOCK		2	60073
IFS REAR LEAF SPRING MODELS PRE 1990	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R <sup>3</sup>
		NITROCHARGER SPORT	SHOCK		2	*60062/60065
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	2.25"	2	CS010R <sup>3</sup>
		NITROCHARGER SPORT	SHOCK		2	60065
REQ'D FOR INSTALLATION (LEAF SPRING- MODELS ONLY)		REAR LEAF SPRING BUSHING KIT			2	OMESB6
		U BOLTS			4	OMEU53 <sup>2</sup>
		STEERING DAMPER			1	OMESD33
		BUSHING SLEEVE			2	181469
	OPTIONAL	GREASABLE SHACKLE KIT			1	OMEGS3
		REAR EXTRA LEAF				D5XL

<sup>1</sup> ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.

<sup>2</sup> INSTALL OE CASTER WEDGES FROM OE SPRING PACK ONTO OME SPRINGS. ENSURE WEDGES ARE FITTED AS PER ORIGINAL POSITION.

<sup>3</sup> COMPARE ORIGINAL SPRING PACK HEIGHT TO OME SPRING PACK TO DETERMINE WHETHER OMEU53 OR OMEU53B U BOLTS ARE REQUIRED.

<sup>4</sup> EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

\* FIRMER VALVED SHOCK

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
ALL LEAF SPRINGS 1984-85	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	2.0"	2	CS008FA/B
		NITROCHARGER SPORT	SHOCK	2.0"	2	60061
		HEAVY LOAD (110-240LBS)	SPRING	2.0"	2	CS009FA/B
		NITROCHARGER SPORT	SHOCK	2.0"	2	60061
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R <sup>7</sup>
		NITROCHARGER SPORT - POST '84	SHOCK	2.0"	2	*60065/60062
		NITROCHARGER SPORT - PRE '84	SHOCK	2.0"	2	*60064/60032
		HEAVY CONSTANT (550LBS TO GVW)	SPRING	2.25"	2	CS010R <sup>7</sup>
		NITROCHARGER SPORT - POST '84	SHOCK	2.25"	2	60065
		NITROCHARGER SPORT - PRE '84	SHOCK	2.25"	2	60064

<sup>1</sup> A/A SPRING FITMENT MAY BE NEEDED ON SOME VEHICLES FOR TRIMMING PURPOSES.

<sup>2</sup> CAN BE USED ON FRONT APPLICATION ONLY

<sup>3</sup> SHOCK SELECTION 60064/60032 FOR MEDIUM AND 60064 FOR HEAVY APPLICATIONS APPLIES TO VEHICLES UP TO 1984 DUE TO A 16MM EYE AND SHORTER OPEN AND CLOSED LENGTHS. POST 1984 VEHICLES WITH 19MM EYE USE 60065/60062 FOR MEDIUM APPLICATIONS AND 60065 FOR HEAVY APPLICATIONS.

<sup>4</sup> OMEU52 IS REQUIRED WHEN FITTING CS009FA/B OR CS008FA/B SPRINGS BECAUSE ORIGINAL U BOLT WILL FOUL DRAG LINK ON FULL DROOP. REFER TO OME FITTING MANUAL.

<sup>5</sup> PICK UP MODELS MAY REQUIRE AN FK03 (SADDLE CORRECTION PLATES) IF THE SPRING SEATS ARE DISTORTED. FK10 MUST BE FITTED TO ALL MODELS USED CONTINUALLY OFF ROAD. REFER TO OME FITTING MANUAL.

<sup>6</sup> EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

<sup>7</sup> A TRIM SPACER MAY BE REQUIRED TO TRIM VEHICLE. ONLY TO BE USED ON REAR SPRINGS. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

## 4RUNNER

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
ALL LEAF SPRINGS 1984-85	REQ'D FOR INSTALLATION	FRONT LEAF SPRING BUSHING KIT			2	OMESB5	
		REAR LEAF SPRING BUSHING KIT			2	OMESB6	
		FRONT U-BOLTS			1	OMEU52 <sup>4</sup>	
		REAR U-BOLTS			4	OMEU53	
		BUSHING SLEEVE			2	181469	
	OPTIONAL	STEERING DAMPER				1	OMESD21
		FRONT GREASEABLE SHACKLE KIT				1	OMEGS4
		REAR GREASEABLE SHACKLE KIT				1	OMEGS3
		GREASEABLE PIN KIT				1	OMEGP3 <sup>2</sup>
		REAR ANTI INVERSION KIT (PRE '84)				1	FK09 <sup>5</sup>
REAR ANTI INVERSION KIT (POST '84)				1	FK13 <sup>5</sup>		
FRONT FITTING KIT				1	FK03/FK10 <sup>5</sup>		
FRONT EXTRA LEAF					D17XL <sup>6</sup>		
REAR EXTRA LEAF					D5XL <sup>6</sup>		
REAR TRIM SPACER					TP04 <sup>7</sup>		

<sup>1</sup> A/A SPRING FITMENT MAY BE NEEDED ON SOME VEHICLES FOR TRIMMING PURPOSES.

<sup>2</sup> CAN BE USED ON FRONT APPLICATION ONLY

<sup>3</sup> SHOCK SELECTION 60064/60032 FOR MEDIUM AND 60064 FOR HEAVY APPLICATIONS APPLIES TO VEHICLES UP TO 1984 DUE TO A 16MM EYE AND SHORTER OPEN AND CLOSED LENGTHS. POST 1984 VEHICLES WITH 19MM EYE USE 60065/60062 FOR MEDIUM APPLICATIONS AND 60065 FOR HEAVY APPLICATIONS.

<sup>4</sup> OMEU52 IS REQUIRED WHEN FITTING CS009FA/B OR CS008FA/B SPRINGS BECAUSE ORIGINAL U BOLT WILL FOUL DRAG LINK ON FULL DROOP. REFER TO OME FITTING MANUAL.

<sup>5</sup> PICK UP MODELS MAY REQUIRE AN FK03 (SADDLE CORRECTION PLATES) IF THE SPRING SEATS ARE DISTORTED. FK10 MUST BE FITTED TO ALL MODELS USED CONTINUALLY OFF ROAD. REFER TO OME FITTING MANUAL.

<sup>6</sup> EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

<sup>7</sup> A TRIM SPACER MAY BE REQUIRED TO TRIM VEHICLE. ONLY TO BE USED ON REAR SPRINGS. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

\* FIRMER VALVED SHOCKS

### ARB ROOF RACKS

YEAR	DESCRIPTION	PART NO.
2003-09	<b>CLASSIC ARB BASKET, TOURING AND FLAT RACKS</b>	
	70" X 44" STEEL RACK WITH MESH FLOOR - KIT	3813010MK4
	70" X 44" STEEL RACK WITHOUT MESH FLOOR - KIT	3813010K4
	70" X 44" ALLOY RACK WITH MESH FLOOR - KIT	4913010MK4
	70" X 44" ALLOY FLAT RACK - KIT	4913020MK4
	70" X 44" STEEL FLAT RACK - KIT	3813030K4
	70" X 49" TOURING RACK - KIT	3813200K
2010-20	<b>CLASSIC ARB BASKET AND FLAT RACKS</b>	
	70" X 44" ALLOY RACK WITH MESH FLOOR - KIT	4913010MK5
	70" X 44" STEEL RACK WITH MESH FLOOR - KIT	3813010MK5
	70" X 44" STEEL RACK WITHOUT MESH FLOOR - KIT	3813010K5
	70" X 44" ALLOY FLAT RACK WITH MESH - KIT	4913020MK5
70" X 44" STEEL FLAT RACK - KIT	3813030K5	
2010-20	<b>ARB BASE RACK SYSTEM</b>	
	61" X 51" BASE RACK KIT - FLAT RACK WITH DEFLECTOR	BASE231
	61" X 51" BASE RACK KIT - FRONT 1/4 BASKET WITH DEFLECTOR	BASE232
	61" X 51" BASE RACK KIT - FRONT 3/4 BASKET WITH DEFLECTOR	BASE233
	61" X 51" BASE RACK KIT - FULL BASKET WITH DEFLECTOR	BASE234
61" X 51" BASE RACK KIT - TRADE RAILS WITH DEFLECTOR	BASE235	

ARB ROOF RACKS		
YEAR	DESCRIPTION	PART NO.
<b>ARB BASE RACK SYSTEM - ACCESSORIES AND MOUNTS</b>		
	BASE RACK TIE DOWN - EYEBOLT - COMES WITH FOUR TIE DOWNS	1780200
	BASE RACK TIE DOWN - SPRING LOADED - COMES WITH TWO TIE DOWNS	1780210
	BASE RACK T-SLOT ADAPTOR - SOLD AS A SINGLE ADAPTOR	1780220
	BASE RACK T-SLOT ADAPTER - SOLD AS A PAIR	1780230
	BASE RACK AWNING BRACKET - FIXED - SOLD AS A SINGLE BRACKET	1780240
	BASE RACK PROPANE BOTTLE HOLDER - 5 TO 20LB TANK	1780250
	BASE RACK AWNING BRACKET - QUICK RELEASE - SOLD AS A SINGLE BRACKET	1780260
	BASE RACK HI-LIFT JACK MOUNT - PREMIUM MOUNT KIT	1780280
	BASE RACK HI-LIFT JACK MOUNT - STANDARD MOUNT KIT	1780290
	BASE RACK RECOVERY BOARD ADAPTOR - REQUIRES RECOVERY BOARD MOUNT	1780310
	JERRY CAN MOUNT - VERTICAL - SINGLE METAL CAN - DOES NOT INCLUDE JERRY CAN	1780320
	JERRY CAN MOUNT - HORIZONTAL - SINGLE METAL CAN - DOES NOT INCLUDE JERRY CAN	1780330
	JERRY CAN MOUNT - VERTICAL - DOUBLE METAL CAN - DOES NOT INCLUDE JERRY CANS	1780340
	JERRY CAN MOUNT - HORIZONTAL - DOUBLE METAL CAN - DOES NOT INCLUDE JERRY CANS	1780350
	BASE RACK ROLLER KIT - FITS 51" WIDE RACKS	1780365
	BASE RACK RATCHET STRAP - 118" STRAP - SOLD AS A PAIR	1780370
	BASE RACK WHEEL MOUNT STRAP - FITS UP TO 35" TIRE	1780380
<b>ARB SLIMLINE LIGHT BAR - MOUNTS TO ARB BASE RACK</b>		
	ARB SLIMLINE BASE RACK LIGHT BAR KIT - INCLUDES BASE RACK BRACKETS	1780500 <sup>1</sup>
	ARB SLIMLINE LIGHT BAR LENS COVER - CLEAR	1780510
	ARB SLIMLINE LIGHT BAR LENS COVER - BLACK	1780511
	ARB SLIMLINE LIGHT BAR LENS COVER - AMBER	1780512
	ARB SLIMLINE LIGHT BAR HARNESS	3500810 <sup>1</sup>
	ARB SLIMLINE LIGHT BAR HARNESS EXTENSION	3500820 <sup>1</sup>

<sup>1</sup> HARNESS PART NUMBER **3500810** REQUIRED FITTING **1780500** SLIMLINE LIGHT BAR. EXTENSION HARNESS **3500820** MAY ALSO BE REQUIRED DEPENDING ON APPLICATION